Victor reader stream 3.1 Cheat Sheet

by a11y_keystroke via cheatography.com/132703/cs/44469/

Change settings

Toggle the **volume, speed** and **tone/pitch** settings	Press **Power** button, **Up** button to Increase amount, **Down** button to decrease.

The Power button toggle mode defaults back to Volumn within few seconds.

Basic keys

1	**Bookshelf** if pressed, **User Guide** if pressed and held
2	Navigation element
3	Delete or Copy
4	Navigate Backward
5	Where am I?
6	Navigate Forward
7	Press for **Menu** or **Text-to-Speech voice Toggle** if pressed and held
8	Navigation Element
9	Text-to-Speech / Recorded audio modes toggle / Random mode toggle (Music)
0	**Info** if pressed, **Key Describer Mode** if pressed and held
*	**Cancel** if pressed, **Key pad Lock** if pressed and held
#	Confirm

To unlock the keypad, press keys 1, 2, and 3 in sequence.

Bookshelf

1 key	Press multiple times to rotate through the circular list of Bookshelves
Go To key (above key 1)	To enter a relative book number
#	To move to the entered book number and remain on the bookshelf
Play key	Start to play from where you left off in the selected book
Go to key	When in Bookshelf the **Go to Page** key becomes a **Go to Book** key

Inside a Book

2 and **8** keys	To choose a navigation level
4 and **6** keys	To move backward and forward between elements at the selected level
*	within 10 seconds to undo the 4 and 6 key actions

These differ from book to book but typically level 1 means chapter, level 2 means section, and level 3 means sub-section and so on.

Delete a book

3 key	To delete the selected item and Stream will ask you to confirm. Press the Pound (#) key to delete or any other key to cancel the delete.

Language and voices

7 (press and hold)	To select an alternate Text-to-Speech voice installed in your Stream
7 (press repeatedly)	To access the language menu
4 or 6	To cycle through choices
Confirm	To save choice

Hard reset

Power key for 2 seconds will not power down the player, keeping the key held for the required hard reset time will still perform a hard reset on release.

By **a11y_keystroke**
cheatography.com/a11y-keystroke/

Published 27th September, 2024.
Last updated 27th September, 2024.
Page 1 of 1.

Sponsored by **Readable.com**
Measure your website readability!
https://readable.com